

Technical Manual 32 and 33 Teletypes sets

Manuel technique des équipements Télétype 32 et 33 (fabricant Teletype Corporation - Illinois, USA)

Il s'agit d'un document Teletype Corporation (Illinois, USA) en 2 volumes, disponible dans la collection de l'ACONIT, Association pour un conservatoire de l'informatique et de la télématique, Grenoble, **fiche n°23766**.

Ces équipements existent en trois types : KSR (Keyboard Send-Receive, un équipement sans commande par bande perforée), RO (Receive-Only), et ASR (Automatic Send-Receive avec commande par bande perforée).

Ces Teletypewriter Sets sont des appareils électromécaniques servant de terminaux pour des communications, en particulier par lignes télégraphe, téléphone ou radio. L'appareil utilise un clavier alphanumérique. Il possède une imprimante. Le type ASR dispose d'un lecteur/perforateur de bande permet d'automatiser certaines opérations.

Les transferts de données se font à la vitesse de 100 mots par minute (page 1).

Ce document est disponible dans la collection de l'ACONIT, Association pour un conservatoire de l'informatique et de la télématique, Grenoble, **fiche n°23766**.

Le document est constitué de deux volumes, soit deux classeurs dont les pages sont assemblées par 2 fois 2 anneaux : Ces volumes comprennent 16 sections totalisant 231 pages pour le premier et 5 sections totalisant 240 pages pour le second. Le volume-1 du document est une troisième édition, datée de 1964 (précédentes 1962, 1963). Le volume-2 est une seconde édition, daté de 1967 (précédente 1964)

Le document comprend de nombreux schémas, plans des pièces, et photos des sous-ensembles de l'appareil. Il décrit en détail les opérations de montage et de maintenance de l'équipement.

Le présent PDF fournit une copie des pages de sommaire du document :

- Une page qui reconstitue les différentes sections, avec leur nombre de pages.
- La page de couverture volume.1
- La page d'index du volume.1, avec les numéros des 16 différentes sections.
- Les tables de matières des 16 sections du volume.1
- La page de couverture volume.2
- La page d'index du volume.2, avec les numéros des 5 différentes sections.
- Les tables de matières des 5 sections du volume.2

D'autres extraits de certains des schémas fournis par ce document sont disponibles dans trois autres fichiers PDF.

[Pour utiliser ce document, mentionnez Teletype Corporation, ainsi que la Base de Données ACONIT n° 23766.](#)

Il est rappelé que la loi sur les droits d'auteur n'autorise que les reproductions partielles de documents à titre individuel et pour des motifs de recherche.

La présente page est une reconstitution des différentes sections du document.

Volume.1

Teletypewriter Set, description :	574-100-102	19 pages
Teletypewriter Set, intallation :	574-100-201	16 pages
Keyboard, Principles of Operation :	574-121-100	8 pages
Keyboard, Lubrification :	574-121-701	4 pages
Keyboard, Disassembly and Reassembly :	574-121-702	3 pages
Typing Unit, Principles of Operation :	574-122-100	43 pages
Typing Unit, Lubrification :	574-122-701	24 pages
Typing Unit, Disassembly and Reassembly :	574-122-702	11 pages
Call Control Unit, Principle of Operation :	574-123-101	45 pages
Tape reader, Principles of Operation :	574-124-100	8 pages
Tape reader, Lubrification :	574-124-701	8 pages
Tape reader, Disassembly and Reassembly :	574-124-702	6 pages
Tape Punch, Principles of Operation :	574-125-100	9 pages
Tape Punch, Lubrification :	574-125-701	9 pages
Tape Punch, Disassembly and Reassembly :	574-125-702	9 pages
Cover, Adjustments, Lubrification and Disassembly and Reassembly :	574-126-100	6 pages

Volume.2 (avec 5 sections) :


Keybord, Adjustments :	574-121-700	20 pages
Typing Unit, Adjustments :	574-122-700	158 pages
Tape Reader, Adjustments :	574-124-700	24 pages
Tape Punch, Adjustments :	574-125-700	29 pages
Cover, Adjustments :	574-126-700	7 pages

BULLETIN 273B
VOL 1

TECHNICAL MANUAL
32 AND 33
TELETYPEWRITER SETS
KEYBOARD SEND-RECEIVE (KSR)
RECEIVE-ONLY (RO)
AUTOMATIC SEND-RECEIVE (ASR)

CONTENTS

DESCRIPTION
DISASSEMBLY AND REASSEMBLY
INSTALLATION
LUBRICATION
PRINCIPLES OF OPERATION



TELETYPE®
CORPORATION

5555 TOUHY AVENUE, SKOKIE, ILLINOIS

November, 1964
Change 4

FILING INSTRUCTIONS

1. The following filing instructions apply to changes sent to the field.
2. Asterisks (*) in the table of contents indicate changes.
3. When the issue of a section changes, replace the old issue with the attached new one.
4. In the case of addendums, turn to the affected section and follow the instructions on the first page of the attached addendum.
5. Replace the old table of contents with this new one.

VOLUME 1

TABLE OF CONTENTS

<u>Equipment</u>	<u>Title</u>	<u>Section</u>	<u>Issue</u>
Teletypewriter Set	Description	574-100-102	1
Teletypewriter Set	Installation	574-100-201	3
Keyboard	Principles of Operation	574-121-100	1
Keyboard	Lubrication	574-121-701	1
Keyboard	Disassembly and Reassembly	574-121-702	1
Typing Unit	Principles of Operation	574-122-100	1
Typing Unit	Lubrication	574-122-701	1
Typing Unit	Disassembly and Reassembly	574-122-702	1
Call Control Unit	Principles of Operation	574-123-101	2*
Tape Reader	Principles of Operation	574-124-100	1
Tape Reader	Lubrication	574-124-701	1
Tape Reader	Disassembly and Reassembly	574-124-702	1
Tape Punch	Principles of Operation	574-125-100	1
Tape Punch	Lubrication	574-125-701	1
Tape Punch	Disassembly and Reassembly	574-125-702	1
Cover	Adjustments, Lubrication, and Disassembly and Reassembly	574-126-100	1

TELETYPE CORPORATION
Skokie, Illinois, U.S.A.

SECTION 574-100-102TC
Issue 1, July, 1964

32 AND 33 TELETYPEWRITER SETS

DESCRIPTION

CONTENTS	PAGE	
1. GENERAL	1	and available accessories. The section describes typical applications and gives pertinent technical data. Also, the section is issued to present the information in a separate section.
2. TELETYPEWRITER SETS	2	
KEYBOARD SEND-RECEIVE (KSR) TELETYPEWRITER SETS	2	1.02 The 32 and 33 Teletypewriter Sets described herein are electromechanical apparatus that provide terminal facilities for exchanging recorded communication via appropriate transmission facilities, including telegraph lines, telephone networks, and radio channels.
RECEIVE-ONLY (RO) TELETYPEWRITER SETS	3	
AUTOMATIC SEND-RECEIVE (ASR) TELETYPEWRITER SETS	3	
ACCESSORIES	3	1.03 References to the "left," "right," "up," "down," "front," or "rear," etc consider the Teletypewriter Set to be viewed from a position where the keyboard cover faces the viewer, with the platen knob to the viewer's left.
3. COMPONENTS	6	1.04 The following Teletypewriter Sets are covered:
KEYBOARD	6	(a) Keyboard Send-Receive (KSR) Teletypewriter Set (Figure 1).
A. KSR and ASR Keyboard	6	(b) Receive-Only (RO) Teletypewriter Set (Figure 2).
B. RO Keyboard	9	(c) Automatic Send-Receive (ASR) Teletypewriter Set (Figures 3 and 4).
TYPING UNIT	9	
MOTOR AND DRIVE PARTS	12	1.05 Transmission and reception are effected by a start-stop signaling code which is carried by the transmission facilities. The basic difference between the 32 and 33 Teletypewriter Sets is that the former utilizes a 5-level code and the latter utilizes an 8-level code. (See the appropriate section for an explanation of codes.) The Teletypewriter Set will operate at speeds up to 100 words per minute (wpm).
CALL CONTROL UNIT	12	
COVER AND SUBBASE	15	
TAPE READER	15	
TAPE PUNCH	16	
4. TYPICAL APPLICATIONS	17	
5. TECHNICAL DATA	18	
1. GENERAL		
1.01 This section is issued to provide a brief description of the 32 and 33 Teletypewriter Sets, together with principal components		

32 AND 33 TELETYPEWRITER SET

INSTALLATION

CONTENTS	PAGE	1. GENERAL
1. GENERAL	1	1.01 This section provides instructions for unpacking, installing, connecting, and preparing the 32 and 33 Teletypewriter Set for use. A 115-volt power source and signal-line current and leads must be furnished by the customer. See the appropriate description section for detailed power and signal-line requirements.
UNPACKING	1	
PREPARATION FOR INSTALLATION	2	
2. INSTALLATION	6	1.02 This section is reissued as a general revision. Because of this, marginal arrows ordinarily used to indicate changes have been omitted.
MOUNTING TYPING UNIT ON STAND	6	
CODING ANSWER-BACK DRUM. . .	6	1.03 References to "left," "right," "front," or "rear," etc, consider the Teletypewriter Set to be viewed from a position where the typing unit carriage faces up and the typing unit selector mechanism is located to the viewer's left.
ADJUSTMENTS	8	
PLACEMENT	8	
ELECTRICAL CONNECTION	9	
3. FINAL ASSEMBLY	9	UNPACKING
GENERAL	9	1.04 The Teletypewriter Set is packed in one carton. Observe all caution and instruction labels on the carton before breaking the seals. Remove the upper filler pads. Carefully take out the typing unit to avoid marring or otherwise damaging the plastic cover. Remove the remaining carton fillers and take out the stand (if used).
RIBBON INSTALLATION	9	
PAPER OR FORM INSTALLATION .	11	
A. Friction Feed	11	
B. Sprocket Feed	11	
4. OPTIONAL FEATURES	12	1.05 The typing unit and subbase are mounted on a wooden shipping pallet by seven screws. Four of the screws are no. 14Z self-tapping screws that secure the subbase to the pallet. The remaining three are standard machine screws that pass through aluminum bushings into tapped holes in the typing unit's base casting. Since the typing unit floats on rubber mounts, it is secured with separate screws. Tilt the mounted typing unit and take out the screw in the countersunk hole first. Loosen the
A. Copy Holder	12	
B. Hum Squelch	13	
C. Busy Circuit	14	
D. Hand Receiver	14	
5. TAPE READER	15	
6. POWER PACK ASSEMBLY	15	
7. TAPE PUNCH	16	

32 AND 33 KEYBOARD
PRINCIPLES OF OPERATION

CONTENTS	PAGE
1. GENERAL	1
2. TRANSMISSION	1
GENERAL	1
KEYBOARD	1
A. Codebar Mechanism	1
B. Universal Mechanism	3
C. Keyboard Contact Mechanism. . .	4
D. Line Break	4
E. Repeat	4
EXAMPLE	4
A. General	4
B. 32 Keyboard	5
C. 33 Keyboard	6

1. GENERAL

1.01 This section is issued to provide principles of operation for the 32 and 33 keyboard and to present the principles as a separate section.

1.02 The teletypewriter code used to transmit messages is described in the appropriate typing unit section. This keyboard section outlines in general terms the overall operation of the keyboard and explains in detail the operation of the components that make it up.

1.03 References to "left," "right," "front," or "rear," etc, consider the keyboard to be viewed from a position where the spacebar faces up and the contact mechanism is located to the viewer's right.

1.04 In the illustrations, fixed pivots are solid black, and floating pivots—those mounted on parts that move—are cross-hatched.

2. TRANSMISSION

GENERAL

2.01 Transmission of messages is accomplished by an operator selectively depressing the keys and spacebar of the keyboard in the same manner as in typing. The downward movement of each key or the spacebar is translated by a codebar mechanism into mechanical arrangement corresponding to the code combination representing the character on the keytop. The mechanical arrangements set up the code combinations in a set of keyboard contacts, and, by parallel output, the code combinations are transmitted to a distributor mechanism. A universal mechanism trips a distributor clutch, and a distributor mechanism then translates the parallel output from the keyboard contacts into corresponding start-stop signal for application to the transmission facilities.

Note: For a further discussion of transmission principles, see the appropriate typing unit section.

KEYBOARD

2.02 In conjunction with a distributor mechanism, the keyboard provides facilities for transmitting messages by the manual operation of a group of keys. The 32 and 33 keyboards are described in the appropriate keyboard section.

A. Codebar Mechanism

2.03 The codebar mechanism is illustrated in Figure 1.

32 AND 33 KEYBOARD

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	2
Codebar mechanism	4
Contact block	3
HERE IS, BREAK, and REPT keylevers	3
Keyboard	2
Keylevers	2
Latchlever hooks	3
Reset bail	4
Spacebar	2
Universal lever	4

Operating Speed (Words per Minute)	Lubrication Interval
60 or 66	1000 hr* or 1 yr**
100	500 hr* or 6 mo**

*Station Set operating hours.
**Whichever comes first.

1.05 The textual instructions that accompany each line drawing consist of abbreviated directions, specific lubrication points, and parts affected. The meanings of the abbreviated directions (symbols) are given below:

Symbol	Meaning
D	Keep dry - no lubricant permitted
OL	Oil liberally (3 or more drops)
OS	Oil sparingly (1 or 2 drops only)
OSD	Oil sparingly or leave dry**
OSL	Oil sparingly or liberally

**Applies to all areas not contacted by other parts.

1.06 References to "left," "right," "front," or "rear," etc consider the keyboard to be viewed from a position where the spacebar faces up and the contact mechanism is located to the viewer's right.

CAUTION: DO NOT USE ALCOHOL, MINERAL SPIRITS, OR OTHER SOLVENTS TO CLEAN PLASTIC PARTS OR PARTS WITH PROTECTIVE - DECORATIVE FINISHES. NORMALLY, A SOFT, DRY CLOTH SHOULD BE USED TO REMOVE DUST, OIL, GREASE, OR OTHERWISE CLEAN PARTS OR SUBASSEMBLIES. IF NECESSARY, A SOFT CLOTH DAMPENED WITH SOAP OR MILD DETERGENT MAY BE USED. AFTERWARDS, RINSE PART OR SUBASSEMBLY WITH A SOFT, DAMP CLOTH AND BUFF WITH A SOFT, DRY CLOTH.

1. GENERAL

1.01 This section is issued to provide instructions for lubricating the 32 and 33 keyboard and to present the lubricating instructions as a separate section.

1.02 The general lubrication areas are illustrated by a photograph. The specific points to receive lubricant are indicated on line drawings with appropriate textual instructions. The line drawings and textual instructions follow the photograph and are keyed to the photograph by paragraph numbers.

1.03 Thoroughly lubricate the keyboard, but avoid over lubrication that might permit the lubricant to drip or be thrown onto adjacent parts. Use KS7470 Oil.

1.04 Lubricate the keyboard before placing it into service or prior to storage. After a short period of service, relubricate it to make sure no areas have been missed. Thereafter, lubricate the keyboard at regular intervals as indicated:

32 AND 33 KEYBOARD

DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY . .	1

1. GENERAL

1.01 This section is issued to provide disassembly and reassembly instructions for the 32 and 33 keyboard and to present the instructions as a separate section.

1.02 References to "left," "right," "front," "rear," etc consider the keyboard to be viewed from a position where the spacebar faces up and the contact mechanism is located to the viewer's right.

1.03 The disassembly procedure given in this section will break the keyboard down into its major assemblies and mechanisms. If further disassembly is required, refer to the appropriate illustrated parts section which shows detailed arrangements of parts. Where it will help in determining their location, the numbers of the parts are given in the instructions.

2. DISASSEMBLY AND REASSEMBLY

CAUTION: BEFORE BEGINNING DISASSEMBLY, REMOVE CONNECTORS FROM EXTERNAL RECEPTACLES (POWER SOURCE, DATA SET, ETC).

2.01 General:

- (a) When self-tapping screws are used to mount mechanisms onto castings, do not remove the self-tapping screws. Merely loosen them enough to remove the mechanisms unless specifically instructed otherwise.

(b) Retaining rings are made of spring steel and have a tendency to release suddenly. To avoid loss of these rings when removing them, proceed as follows:

- (1) Hold retaining ring to prevent its rotating.
- (2) Place blade of screwdriver in one of ring's slots and rotate screwdriver to increase diameter.
- (3) Ring will come off easily in fingers without flying.

2.02 To remove keyboard and call control unit, proceed as follows:

Note: Reference Figures 1 and 2.

- (1) Remove the keyboard plug from its receptacle on the call control unit.
- (2) Remove four TP121551 mounting screws and remove call control unit.
- (3) Disengage keyboard cable from TP182531 cable clips on subbase.
- (4) Insert screwdriver in slot in TP180977 H-plate and push to left against pressure of spring until H-plate is disengaged from universal lever. Remove H-plate.

Note: If the typing unit has been removed from its seat on the subbase, the H-plate will already have been removed.

- (5) Loosen two TP180798 keyboard mounting screws. Slide keyboard assembly to rear and lift it from subbase.

32 AND 33 TYPING UNIT
PRINCIPLES OF OPERATION

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1	C. Power	19
TELETYPEWRITER CODE	2	D. Rotary Positioning	19
A. 32 Typing Units	2	E. Vertical Positioning	24
B. 33 Typing Units	2	F. Printing Mechanism	26
GENERAL OPERATION	5	G. Ribbon Mechanism	28
A. Power Distribution	5	H. Example	29
B. Power Transmission	5	SPACING.	31
C. Reception and Printing	5	A. General	31
D. Function Mechanism	5	B. With Printing	31
E. Spacing Mechanism	5	C. Space Suppression	31
F. Paper Feed Mechanism (Friction Feed Typing Units)	5	D. Space Function	31
G. Form-Out Mechanism (Sprocket Feed Typing Units)	6	E. Carriage Return	32
2. DETAILED PRINCIPLES OF OPERATION	6	PAPER OR FORM FEEDING	33
POWER DISTRIBUTION	6	A. Friction Feed Typing Units	33
A. Motor	6	B. Sprocket Feed Typing Units	35
B. Distribution	6	END-OF-LINE BELL	38
C. Clutches	6	AUTOMATIC CARRIAGE RETURN- LINE FEED	38
TRANSMISSION	6	ANSWER-BACK MECHANISM	39
A. General	6	A. General	39
B. Distributor Mechanism	10	B. Drum	41
RECEPTION AND CONVERSION	13	C. Remote Actuation—Function Mechanism	41
A. Selector Mechanism	13	D. Local Actuation—HERE-IS Key.	42
B. Range Finder	16	E. First Character Suppression	42
C. Codebar Mechanism	16	F. Answer-Back Suppression on Transmission	42
FUNCTION MECHANISM.	17	G. Length of Answer-Back Sequence	43
PRINTING	19	1. GENERAL	
A. General	19	1.01 This section is issued to provide prin- ciples of operation for the 32 and 33 typing unit and to present the principles as a	
B. Typewheel	19		

32 AND 33 TYPING UNIT

LUBRICATION

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1	Stop bail	4
2. BASIC UNITS	2	Trip lever	3
COMMON MECHANISMS	2	Trip shaft	5
Armature	7	Typewheel mechanism	15
Automatic codebar	8	FRICITION FEED MECHANISMS	18
Blocking levers	8	Line feed mechanism	19
Carriage area	13	Paper feed area	18
Carriage return and spacing levers ..	11	Platen	18
Codebars	9	SPROCKET FEED MECHANISMS ...	19
Codebar clutch	5	Cam, pulley, and gear combination ..	21
Dashpot	13	Form-out mechanism	22
Disc and brushes	3	Line feed clutch	22
Distributor area	2	Paper feed area	19
Drive mechanism	12	Platen mechanism	20
Function area	8	Platen drive area	21
Function clutch	5	3. VARIATIONS TO BASIC UNITS	23
Function levers	10	Answer-back area	23
Intermediate gears	17	Answer-back mechanism	24
Latchlever	3	Trip magnet	23
Latchlever and trip lever	6	1. GENERAL	
Main shaft area	4	1.01 This section is issued to provide in-	
Motor	17	structions for lubricating the 32 and 33	
Motor area	17	typing unit and to present the lubricating in-	
Print hammer	14	structions as a separate section.	
Push levers and stripper bail	7	1.02 The general lubrication areas are illus-	
Reset arm	14	trated by photographs. The specific	
Reset bail	9	points to receive lubricant are indicated on	
Ribbon guide spring	15	line drawings with appropriate textual instruc-	
Ribbon mechanism	16	tions. Line drawings and textual instructions	
Rocker and pawls	9	follow each photograph and are keyed to the	
Selector area	6	photograph by paragraph numbers.	
Selector clutch	6		
Selector levers	7		
Slides	16		
Slide guide plates - 1	14		
Slide guide plates - 2	15		
Spacing area	10		
Space bellcrank	10		
Spacing mechanism - 1	11		
Spacing mechanism - 2	12		

32 AND 33 TYPING UNIT

DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL.....	1
2. DISASSEMBLY AND REASSEMBLY ..	1

1. GENERAL

1.01 This section is issued to provide disassembly and reassembly instructions for the 32 and 33 typing unit and to present the instructions as a separate section.

1.02 References to "left," "right," "front," or "rear," etc consider the typing unit to be viewed from a position where the ribbon mechanism faces up and the selector mechanism is located to the viewer's left.

1.03 The disassembly procedure given in this section will break the typing unit down into its major assemblies and mechanisms. If further disassembly is required, refer to the appropriate illustrated parts section which shows detailed arrangements of parts. Where it will help in determining their location, the numbers of the parts are given in the instructions.

2. DISASSEMBLY AND REASSEMBLY

CAUTION: BEFORE BEGINNING DISASSEMBLY, REMOVE CONNECTORS FROM EXTERNAL RECEPTACLES (POWER SOURCE, DATA SET, ETC).

2.01 General:

(a) Most of the mechanisms are mounted on castings by self-tapping screws. Therefore, to remove the mechanisms, do not remove the screws. Merely loosen them unless specifically instructed otherwise.

(b) Retaining rings are made of spring steel and have a tendency to release suddenly. To avoid loss of these rings when removing them, proceed as follows:

- (1) Hold retaining ring to prevent its rotating.
- (2) Place blade of screwdriver in one of ring's slots and rotate screwdriver to increase diameter.
- (3) Ring will come off easily in fingers without flying.

2.02 Common Mechanisms:

(a) To remove typing unit proceed as follows:

Note: Reference Figures 1, 2, and 3.

(1) Remove all plugs which terminate wires leading from the typing unit from their receptacles on call control unit. Remove ground strap from ground tab on call control unit.

(2) Insert screwdriver in slot in TP180977 H-plate and push to left against pressure of spring until plate is disengaged from universal lever. Remove H-plate.

Note: If the keyboard has been disassembled from the subbase, the H-plate will already have been removed. See the appropriate keyboard section.

(3) Lift typing unit from subbase.

(4) To replace typing unit, reverse procedure used to remove it. Make sure that the typing unit is properly seated on rubber isolators and TP180831 answer-back bellcrank is under and aligned with

TELETYPE CORPORATION
Skokie, Illinois, U.S.A.

SECTION 574-123-101TC
Issue 2, October, 1964

32 AND 33 CALL CONTROL UNIT

PRINCIPLES OF OPERATION

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	3. CALL CONTROL UNIT - BELL SYSTEM SWITCHED NETWORK SERVICE	25
2. CALL CONTROL UNIT - WESTERN UNION "TELEX" SERVICE	3	OPERATION	25
OPERATION	3	A. General	25
A. General	3	B. Power Requirements	26
B. Neutral Signaling Condition	3	PROGRESS OF A CALL	26
C. Polar Signaling Condition	5	DISCONNECTING A CALL	26
POWER SUPPLY	5	ANSWERING A CALL	27
LOCAL-REMOTE CONTROL CIRCUITS	6	A. Manual Answering	27
A. General	6	B. Automatic Answering	27
B. Proceed-to-Dial Circuit	6	LOCAL MODE	27
C. Connect Circuit	7	"OUT OF SERV." SWITCH	27
D. Local Circuit	9	LOW-PAPER ALARM	28
E. Circuit Interconnections	10	RESTRAIN LAMP	28
F. Idle Line Condition	11	TEST MODE	28
G. Initiating a Call	11	SIGNAL GENERATION	29
H. Connection	13	SELECTOR MAGNET DRIVER	29
I. Disconnect	14	A. General	29
J. Local Off-Line Operation	14	B. Circuit Description	29
SELECTOR MAGNET DRIVER	14	SPEAKER AMPLIFIER SYSTEM	30
MOTOR DELAY TIMER	15	DIALER MECHANISMS	31
POLAR ADAPTER	17	A. Pulsing Rotary Dialer	31
A. General	17	B. Pulsing Card Dialer (40A Dialer)	31
B. Receiving Polar Relay	17	C. Pulsing Card Dialer (41A Dialer)	32
C. Sending Polar Relay	18	D. TOUCH-TONE Dialer	33
D. Connect Control Timer	18	E. TOUCH-TONE and Card Dialer	35
E. Current Amplifier	21	4. CALL CONTROL UNIT - PRIVATE WIRE SERVICE	36
F. Circuit Interconnections	21	OPERATION	36
G. Idle Line Condition	21	POWER SWITCH	36
H. Initiating a Call	21		
I. Proceed-to-Dial	24		
J. Dialing	24		
K. Call Connection	24		
L. Remote Connection	24		
M. Call Disconnect	25		
N. Remote Disconnect	25		
O. Local Off-Line Operation	25		

CONTENTS	PAGE
5. CALL CONTROL UNIT—CIRCUIT SWITCHING SERVICE.....	38
OPERATION	38
A. General	38
B. Idle Signal Line	38
C. Request Circuit	38
D. Connect Circuit	38
E. Disconnect Circuit	38
F. Remote Disconnect Circuit.....	38
G. Busy Signal	38
H. Local Circuit.....	39
ANALYSIS OF CIRCUITS.....	39
A. Selector Magnet Driver.....	39
B. Motor Delay Timer.....	39
C. Polar Adapter	39
D. Request Circuit	39
E. Connect Circuit	40
F. Local Circuit.....	41
G. Circuit Interconnections	41
H. Idle Line Condition.....	42
I. Initiating a Call	42
J. Call Connection	43
K. Remote Connection.....	43
L. Call Disconnect	44
M. Remote Disconnect.....	44
N. Local Off Line Operation.....	45

1. GENERAL

1.01 This section is reissued to add coverage of the circuit switching call control unit. Since all changes are in 1.01, 1.06, and 5.01 through 5.52, marginal arrows are omitted.

1.02 The function of a call control unit is to couple a teletypewriter either to telegraph networks or, through a data set, to telephone networks. In some applications, the call control unit provides facilities for initiating, accepting, controlling, and completing calls; while in others, it acts as a connecting device only.

1.03 The call control unit used in Western Union TELEX service operates over short and intermediate length telegraph loops using neutral signaling or over longer loops with polar signaling when modified with proper polar-to-neutral converting circuitry. It includes a power supply, local-remote control circuits, a selector magnet driver circuit, and a motor delay timer circuit. Paragraphs 2.01 to 2.13 outline in general terms the call control unit's overall operation. Paragraphs 2.14

through 2.48 explain its detailed operation. The applicable schematic wiring diagram is 4779WD.

1.04 The call control unit is used in Bell System switched network service. When it is connected with the appropriate data set, it is connected with conventional telephone central offices having the required routing and message accounting equipment. These are generally the same offices and equipment serving telephone customers in the area. Direct current signals are used for both originating and terminating traffic—providing the same conditions as for conventional local telephone set operation. The dial on the call control unit, for initiation of call connections, may be either a dc pulsing or a multifrequency (MF) tone device. Also included in the call control unit are ringing or tone sounding apparatus for alerting the called party. Paragraphs 3.01 through 3.06 outline in general terms the call control unit's overall operation. Paragraphs 3.08 through 3.32 explain its detailed operation. The principal applicable schematic wiring diagram is 5918WD. For additional wiring information, see the pertinent wiring diagrams, associated with the call control unit or, when provided, the appropriate section.

1.05 The call control unit used in private wire service operates over short or intermediate length telegraph loops using neutral dc signaling. It includes a power supply, a selector magnet driver circuit and a power switch. Paragraphs 4.01 through 4.03 describe the call control unit generally, and paragraph 4.04 through 4.07 explain in detail its only manual control—the power switch. For wiring information see either 6353WD or 6355WD. For further wiring information see wiring diagram(s) associated with the particular call control unit or (when provided) appropriate section.

1.06 The call control unit used in a circuit switching network operates over short and intermediate length telegraph loops using neutral signaling or over longer loops with polar signaling when modified with proper polar-to-neutral converting circuitry. It differs from the call control unit used in Western Union TELEX service primarily in the call originating circuitry. Paragraphs 5.01 through 5.10 outline the unit's overall operation. Paragraphs 5.11 through 5.52 explain its operation in detail. The applicable wiring diagrams are 7227WD, 7267WD, and 6481WD.

Note: This unit can also be used in 35 equipment for certain circuit switching applications.

32 AND 33 TAPE READER

PRINCIPLES OF OPERATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT OPERATION	1
GENERAL	1
AUTOMATIC READER CONTROL	7

1. GENERAL

1.01 This section is issued to provide principles of operation for the 32 and 33 tape reader and to present the principles as a separate section.

1.02 The teletypewriter code used to transmit messages is described in the appropriate typing unit section. This tape reader section outlines in general terms the overall operation of the tape reader and explains in detail the operation of the components that make it up.

1.03 References to "left," "right," "front," "rear," etc, consider the tape reader to be viewed from a position where the feed wheel faces up and the tape lid latch handle is to the viewer's right.

1.04 In the illustrations, fixed pivots are solid black, and floating points—those mounted on parts that move—are cross hatched.

2. BASIC UNIT OPERATION

GENERAL

2.01 The tape reader (Figure 1) attaches to the typing unit subbase at the left side of the keyboard. The distributor clutch trip mechanism (see Figure 4) is assembled into

the typing unit distributor. The power pack is attached inside the typing unit stand. The tape reader is designed to sense code combinations perforated in a tape.

2.02 To initiate operation the tape lid latch handle (Figures 1 and 2) is moved to the right, releasing the tape lid, and allowing the tape lid to swing open. The tape is placed on the feed wheel in its proper position, and the tape lid is closed.

2.03 There are three basic positions for the control lever (Figures 1 and 3): START, STOP, and FREE. In the basic tape reader only, a control contact and control contact wires are used in conjunction with the control lever. When the control lever is moved to the START position, the control contact and control contact wires are closed. In the basic tape reader, the control contact and control contact wires are wired in series with the distributor clutch trip coil, which is located in the distributor area of the typing unit.

2.04 The distributor clutch trip coil (Figure 4), when energized, releases the tape reader trip lever. The tape reader trip lever, when released, performs two functions. First, the tape reader feed magnet contacts, which are held open by an insulator on the backside of the tape reader trip lever, closes. In its continued travel, a projection on the tape reader trip lever rotates the distributor clutch stop bail, releasing the distributor clutch and initiating a distributor cycle.

2.05 The tape reader feed magnet contacts (Figure 5) having closed, cause the feed magnet coil in the tape reader package to be energized. The feed magnet coil, upon energization, attracts the armature.

32 AND 33 TAPE READER

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	2
Armature shaft	4
Clutch trip area	6
Control mechanism	5
Feed pawl mechanism	5
Feed wheel	4
Tape lid mechanism	6
Tape reader	2
Tape reader mechanism	3
Tight-tape mechanism	4
Trip magnet mechanism - 1	7
Trip magnet mechanism - 2	7
Trip magnet mechanism - 3	8

1. GENERAL

1.01 This section is issued to provide instructions for lubricating the 32 and 33 tape reader and to present the lubricating instructions as a separate section.

1.02 The general lubrication areas are illustrated by photographs. The specific points to receive lubricant are indicated on line drawings with appropriate textual instructions. Line drawings and textual instructions follow each photograph and are keyed to the photograph by paragraph numbers.

1.03 Thoroughly lubricate the tape reader, but avoid over lubrication that might permit the lubricant to drip or be thrown onto adjacent parts. Use the following lubricants:

Oil KS7470
Grease KS7471
Grease 108805

1.04 Lubricate the tape reader before placing it into service or prior to storage. After a short period of service, relubricate it to make sure no areas have been missed. Thereafter, lubricate the tape reader at regular intervals as indicated below:

Operating Speed (Words per Minute)	Lubrication Interval
60 or 66	1000 hr* or 1 yr**
100	500 hr* or 6 mo**

*Station Set operating hours.

**Whichever comes first.

1.05 The textual instructions that accompany the line drawings consist of abbreviated directions, specific lubrication points, and parts affected. The meanings of the abbreviated directions (symbols) are given below:

Symbol	Meaning
D	Keep dry - no lubricant permitted
G	Apply thin coat of KS7471 Grease
GOL	Brush on well a mixture of 50% KS7471 Grease and 50% KS7470 Oil
L	Apply a thin coat of 108805 Grease
OL	Oil liberally (3 or more drops)
OS	Oil sparingly (1 or 2 drops only)
OSD	Oil sparingly or leave dry**
OSL	Oil sparingly or liberally

**Applies to all areas not contacted by other parts.

32 AND 33 TAPE READER
DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL.....	1
2. DISASSEMBLY AND REASSEMBLY ..	1

1. GENERAL

1.01 This section is issued to provide disassembly and reassembly instructions for the 32 and 33 tape reader and to present the disassembly and reassembly instructions as a separate section.

1.02 References to "left," "right," "front," "rear," etc, consider the tape reader to be viewed from a position where the feed wheel faces up and the lid latch is to the viewer's right.

1.03 The disassembly procedure given in this section will break the tape reader down into its major assemblies and mechanisms. If further disassembly is required, refer to the appropriate illustrated parts section which shows detailed arrangements of parts. Where it will help in determining their location, the numbers of the parts are given in the instructions.

2. DISASSEMBLY AND REASSEMBLY

CAUTION: THE TAPE READER FEED MAGNET AND TRIP MAGNET OPERATE UNDER HIGH VOLTAGE. PRECAUTIONARY MEASURES SHOULD BE TAKEN WHENEVER POWER TO THE TAPE READER IS TURNED ON. HIGH VOLTAGE FROM THE POWER PACK WILL CONTINUE UNTIL APPROXIMATELY 10 SECONDS AFTER THE TAPE READER HAS BEEN DISCONNECTED.

2.01 General:

(a) When self-tapping screws are used to mount mechanisms onto castings, do not remove the self-tapping screws. Merely loosen them enough to remove the mechanisms unless specifically instructed otherwise.

(b) Retaining rings are made of spring steel and have a tendency to release suddenly. To avoid loss of these rings when removing them, proceed as follows:

- (1) Hold retaining ring to prevent its rotation.
- (2) Place blade of screwdriver in one of ring's slots and rotate screwdriver to increase diameter.
- (3) Ring will come off easily in fingers without flying.

2.02 The tape reader and cover are assembled at the factory.

2.03 The tape reader cover is fastened to the typing unit cover with two TP181244 screws, four TP7002 washers, two TP124177 lockwashers, and two TP3598 nuts. The two covers are assembled with the bottom surface of the covers flush with each other.

(a) The tape reader and typing unit cover assembly is fastened to the typing unit subbase as described in the appropriate cover section.

Note: The left rear corner of the tape reader cover is secured to the tape reader base casting with a screw.

(b) With the tape reader and cover assembly secured in position, there shall be equal clearance on three sides between the

32 AND 33 TAPE PUNCH
PRINCIPLES OF OPERATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT OPERATION	1
GENERAL	1
DRIVE LINK MECHANISM	7
CONTROL MECHANISM	7
3. VARIATIONS TO BASIC UNIT	7
FIGS "D".	7
AUTOMATIC CONTROLS	9

1. GENERAL

1.01 This section is issued to provide principles of operation for the 32 and 33 tape punch and to present the principles as a separate section.

1.02 The tape punch's basic function is to convert start-stop electrical signals into a form that can be stored. It accomplishes this function by punching holes into tape according to a teletypewriter code. The teletypewriter code is described in the appropriate typing unit section. This tape punch section outlines in general terms the overall operation of the tape punch and explains in detail the operation of the components that make it up.

1.03 References to "left," "right," "front," or "rear," etc, consider the tape punch to be viewed from a position where the tape guide assembly faces up and the backspace lever is to the viewer's left.

1.04 In the illustrations, fixed pivots are solid black and floating points—those mounted on parts that move—are cross hatched.

2. BASIC UNIT OPERATION

GENERAL

2.01 The tape punch attaches to the left side of the typing unit base casting. The individual mechanisms and subassemblies that form the tape punch mount on the tape punch base casting, which serves as the main structural member.

2.02 Rotation of the typing unit's function rocker shaft provides a pre-determined controlled motion for the drive mechanism (Figure 1). The drive mechanism oscillates about a post mounted to the tape punch base casting and receives its motion from the typing unit's function rocker shaft through the drive link mechanism (Figure 1). This motion is transferred to the nudger, tape feed mechanism, and into the punch mechanism to perform the tape feed functions.

2.03 The individual members that compose the drive mechanism perform the following functions.

(a) Drive Post: The drive link imparts motion to the drive mechanism through the drive post.

(b) Nudger Arm: There is a cam profile perforated in the nudger arm which transfers motion to the nudger.

(c) Feed Pawl Arm: The feed pawl derives its motion from the feed pawl arm.

(d) Stripper Bail: The stripper bail pivots from a post that is supported by the nudger and feed pawl arms.

(e) Sensing Lever Bail: Motion is transferred to the sensing levers through a post supported by the nudger and feed pawl arms.

32 AND 33 TAPE PUNCH

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	2
Backspace lever	5
Codebar levers	4
Control mechanism	7
Detent lever	5
Drive link	8
Drive link mechanism	9
Drive link mechanism area	8
Feed mechanism	3
Feed pawl	5
Pawls and levers	4
Punch block assembly	7
Sensing levers	3
Stripper bail	4
Tape guide assembly	6
Tape guide roller	6
Tape punch	2

1. GENERAL

1.01 This section is issued to provide instructions for lubricating the 32 and 33 tape punch and to present the lubricating instructions as a separate section.

1.02 The general lubrication areas are illustrated by photographs. The specific points to receive lubricant are indicated on line drawings with appropriate textual instructions. Line drawings and textual instructions follow each photograph and are keyed to the photograph by paragraph numbers.

1.03 Thoroughly lubricate the tape punch, but avoid over lubrication that might permit the lubricant to drip or be thrown onto adjacent parts. Saturate all felt washers and oilers with oil. Use KS7470 Oil where oil is required and KS7471 Grease where grease is required.

1.04 Lubricate the tape punch before placing it into service or prior to storage. After a short period of service, relubricate it to make sure no areas have been missed. Thereafter, lubricate the tape punch at regular intervals as indicated below:

Operating Speed (Words per Minute)	Lubrication Interval
60 or 66	1000 hr* or 1 yr**
100	500 hr* or 6 mo**

*Station Set operating hours.

**Whichever comes first.

1.05 The textual instructions that accompany the line drawings consist of abbreviated directions, specific lubrication points, and parts affected. The meanings of the abbreviated directions (symbols) are given below:

Symbol	Meaning
D	Keep dry - no lubricant permitted
G	Apply thin coat of KS7471 Grease
GOL	Brush on well a mixture of 50% KS7471 Grease and 50% KS7470 Oil
OL	Oil liberally (3 or more drops)
OS	Oil sparingly (1 or 2 drops only)
OSAT	Saturate with oil (all washers and oilers)
OSD	Oil sparingly or leave dry**
OSL	Oil sparingly or liberally

**Applies to all areas not contacted by other parts.

32 AND 33 TAPE PUNCH

DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL.....	1
2. DISASSEMBLY AND REASSEMBLY ..	1

1. GENERAL

1.01 This section is issued to provide disassembly and reassembly instructions for the 32 and 33 tape punch and to present the instructions as a separate section.

1.02 References to "left," "right," "front," "rear," etc consider the tape punch to be viewed from a position where tape guide assembly faces up and the backspace lever is to the viewer's left. Orientation references in the drive link mechanism area consider the drive link to be up and located to the viewer's left.

1.03 The disassembly procedure given in this section will break the tape punch down into its major assemblies and mechanisms. If further disassembly is required, refer to the appropriate illustrated parts section which shows detailed arrangement of parts. Where it will help in determining their location, the numbers of the parts are given in the instructions.

2. DISASSEMBLY AND REASSEMBLY

CAUTION: BEFORE BEGINNING DISASSEMBLY, REMOVE CONNECTORS FROM EXTERNAL RECEPTACLES (POWER SOURCE, DATA SET, ETC.).

2.01 General:

(a) When self-tapping screws are used to mount mechanisms onto castings, do not remove the self-tapping screws. Merely loosen them enough to remove the mechanisms unless specifically instructed otherwise.

(b) Retaining rings are made of spring steel and have a tendency to release suddenly. To avoid loss of these rings when removing them, proceed as follows:

- (1) Hold retaining ring to prevent its rotating.
- (2) Place blade of screwdriver in one of ring's slots and rotate screwdriver to increase diameter.
- (3) Ring will come off easily in fingers without flying.

2.02 To disassemble the parts of the tape punch cover assembly, proceed as follows:

Note: Reference Figure 1.

- (1) Remove the composite cover — tape punch cover assembly, tape reader cover, and typing unit cover and lid from the subbase of a 5-level or 8-level Automatic Send-Receive Teletypewriter Set as described in the appropriate cover section.
- (2) Unsnap the tape punch lid assembly from the bosses located in both halves of the tape punch cover assembly.
- (3) Remove the six screws, twelve flat washers, six lockwashers, and six nuts that secure the tape punch cover to the composite cover.

Note: The heads of the screws, when assembled, shall be on the inside wall of the right cover half.

- (4) Remove the two TP182916 screws and one TP180798 screw that secure the right cover half to the left cover half.
- (5) Separate TP182922 left cover half from the TP182921 right cover half.

32 AND 33 COVER

ADJUSTMENTS, LUBRICATION, AND DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. ADJUSTMENTS	1
Dial to cover	3
Knob to bezel	3
3. LUBRICATION	4
Cover	5
Lid	5
4. DISASSEMBLY AND REASSEMBLY . .	6

1. GENERAL

1.01 This section is issued to provide adjustment, lubrication, and disassembly and reassembly information for the 32 and 33 cover and to present the information as a separate section.

1.02 A plastic cover such as is shown in Figure 1 provides a decorative and protective enclosure for the typing unit, keyboard, and call control unit. A lid, which is spring detented in its open position, may be raised to gain access to the typing unit for replenishing such items as paper and ribbon. A window permits viewing the copy and provides a cutting edge for tearing paper or forms. Slots at the rear of the cover hold the

paper roll spindle. Mounting slots are provided for a copy holder. A nameplate (Figure 2) is mounted at the front.

1.03 The cover is mounted at its outer edges on a cast subbase (Figure 2) which serves as a foundation for the keyboard, typing unit, and call control unit. Rubber vibration isolators support the typing unit.

1.04 Reference to "left," "right," "front," or "rear," etc, consider the cover to be viewed from a position where the lid is up and the nameplate position is facing toward the viewer.

2. ADJUSTMENTS


2.01 In the adjustments covered in this section, location of clearances and position of parts are illustrated by line drawings. Requirements and procedures are set forth in the texts that accompany the line drawings.

2.02 If the mounted cover and/or other parts are removed to facilitate the making of an adjustment, replace it and/or the other parts after making the adjustment. Recheck any adjustments that may have been affected by the removal of the cover and/or other parts.

2.03 Unless specifically stated otherwise, make screws or nuts friction tight to make an adjustment, and tighten them securely once the adjustment has been made.

**BULLETIN 310B
VOL 2**

**TECHNICAL MANUAL
33 TELETYPEWRITER SETS
KEYBOARD SEND-RECEIVE (KSR)
RECEIVE-ONLY (RO)
AUTOMATIC SEND-RECEIVE (ASR)**



**TELETYPE[®]
CORPORATION**

5555 TOUHY AVENUE, SKOKIE, ILLINOIS

310B
Volume 2

INTRODUCTION

Bulletin 310B is a technical manual that provides general and specific information about the 33 Keyboard Send-Receive (KSR), Receive-Only (RO), and Automatic Send-Receive (ASR) Teletypewriter Sets and their component units. It consists of two volumes.

Volume 1 contains a description of the 33 Teletypewriter Sets and gives installation instructions. Also included in Volume 1 is information on the disassembly and reassembly, lubrication, and principles of operation of the component units of the Teletypewriter Sets. Volume 2 includes adjustment information on all component units of 33 Teletypewriter Sets.

Each volume is made up of a group of appropriate independent sections. Each independent section is complete within itself—it is separately identified by a title and section number, and the pages are numbered consecutively.

Each individual section is identified by a 9-digit section number which appears at the top of each page of a section. The section number appears on the left corner of left-hand pages and on the right corner of right-hand pages. In addition, the section number on each page contains the suffix TC which identifies it as a Teletype Corporation section. All sections are placed in the technical manual in ascending numerical order.

To locate specific information, refer to the table of contents on the following page. In the first column, under "Equipment," find the name of the component unit or set in question. Move across the page to the second column and locate the title being sought. The applicable 9-digit section number can then be found in the third column. Turn to Page 1 of the applicable section, and the contents of that section will be found.

TABLE OF CONTENTS

<u>Equipment</u>	<u>Title</u>	<u>Section</u>	<u>Issue</u>
Keyboard	Adjustments	574-121-700TC	2
Typing Unit	Adjustments	574-122-700TC	3
Tape Reader	Adjustments	574-124-700TC	2
Tape Punch	Adjustments	574-125-700TC	3
Cover	Adjustments	574-126-700TC	1

TELETYPE CORPORATION
Skokie, Illinois, U. S. A.

SECTION 574-121-700TC
Issue 2, July, 1967

33 KEYBOARD

ADJUSTMENTS

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	5
BREAK keylever spring.	12
Contact block spring.	10
Contact wires	6
Contact wire spring	10
CTRL contact wire.	8, 9
CTRL keylever spring.	12
Distributor trip linkage.	19
HERE IS keylever spring.	12
Keylever spring.	11
Keylever springs (SPACE, BLOCK, hyphen, or O keytops).	13
Latchlever spring.	20
Left shift contact wire.	7
Nonrepeat lever spring	17
REPT keylever spring.	12
Reset bail spring	14
Shift codebar spring	16
Spacebar spring	11
Universal lever spring	18
Universal link	5
Universal link spring	15

1. GENERAL

1.01 This section provides adjustment information for 33 keyboards which are mechanically reset by an H-plate and the distributor trip linkage shown in 2.14. It is reissued to include information only on 33 keyboards. Also, this issue updates information and adds new information on the auxiliary contact mechanism used on parity keyboards and keylever springs used on numeric-type keyboards. Since this is a general revision, marginal arrows ordinarily used to indicate changes and additions are omitted.

Note: Adjustment information for solenoid-reset keyboards is found in another section.

1.02 In the adjustments covered in this section, location of clearances, position of parts, and point and angle of scale applications are

illustrated by line drawings. Requirements and procedures are set forth in the several texts that accompany the line drawings. Tools necessary to maintain 33 Teletypewriter Sets are shown in Maintenance Tools Section 570-005-800TC.

1.03 The sequence in which the adjustments appear is that which should be followed when a complete readjustment of the keyboard is undertaken. No single adjustment should be undertaken without first completely understanding the procedure and knowing the requirements. Therefore, read a procedure all the way through before making an adjustment or checking a spring tension.

Note: Disconnect the keyboard from any voltage source prior to inspection, minor repair, extensive maintenance, or a complete readjustment.

1.04 References to left, right, front, rear, etc consider the keyboard to be viewed from a position where the spacebar (Figure 3) faces up and the contact mechanism is located to the viewer's right.

1.05 When a procedure calls for using pry points or slots to make an adjustment, place a screwdriver between the points or in the slots and pry parts in the proper direction.

1.06 When the keyboard is removed from the subbase to facilitate the making of an adjustment and subsequently replaced, recheck any adjustments that may have been affected. Also, if parts are removed from the keyboard to facilitate the making of an adjustment, be sure that they are subsequently replaced. Recheck any adjustment that may have been affected by the removal of parts.

1.07 Related adjustments are listed with some of the adjustment texts and are primarily intended to aid in troubleshooting the equipment. As an example, suppose that in searching for a trouble it is discovered that Part (2) of CONTACT WIRES adjustment does not meet its requirement. Under Related Adjustment it is indicated that Part (2) of this adjustment is affected by Part (1). Check Part (1) to see if it is the basic

TELETYPE CORPORATION
Skokie, Illinois, U. S. A.

SECTION 574-122-700TC
Issue 3, December, 1967

33 TYPING UNIT

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	3	Stop bail spring	13
2. BASIC UNIT	9	Trip lever engagement	127
Carriage Area		Trip shaft position	10
Final printing alignment	129	Form Feed Area	
Fourth pulse linkage positioning	59	Cam lobe position - S	74
Front rollers clearance	50	Clutch shoe lever gap - S	71
Left slide guideplate reset	67	Form feed belt tension - S	70
Power bail roller clearance	51	Form-out bail spring - S	84
Print drive lever positioning	55	Form-out contact operating bail	
Print hammer bail spring	57	clearance - S	84
Print hammer trip lever spring	57	Form-out contact pressure and gap - S	84
Print suppression latchlever		Form-out lever overtravel - S	73
endplay	62	Form-out lever — reset clearance	
Print suppression latchlever		(early design) - S	77
release	63	Form-out lever — reset clearance	
Print trip lever release	58	(late design) - S	78
Print trip lever reset	61	Form-out lever spring - S	73
Rack and pinion backlash	51	Latchlever assembly spring - S	73
Rear rail position	54	Latchlever spring - S	71
Rear roller clearance	55	Line feed bail spring - S	82
Reset lever positioning	60	Line feed lever line-up and	
Ribbon drive lever spring	64	endplay - S	72
Ribbon feed pawl spring	64	Line feed lever spring - S	82
Ribbon guide spring	57	Line feed pawl stripping - S	83
Ribbon positioning	68	Line feed selection - S	82
Ribbon power lever drive	69	Reset follower lever spring - S	74
Ribbon ratchet spring	64	Trip lever engagement — final - S	80
Ribbon reverse arm spring	64	Trip lever engagement —	
Right slide guideplate reset	66	form-out - S	75
Rotary drive bail spring	52	Trip lever engagement —	
Slide guideplate springs	56	line feed - S	79
Slide springs	53	Trip lever engagement —	
Typewheel "home" position	65	preliminary - S	76
Typewheel positioning	56	Trip lever spring - S	71
Typewheel return spring	52	Trip lever upstop position - S	81
Vertical drive bail spring	52	Trip shaft endplay - S	72
Distributor Area		Function Area	
Brush holder gap	9	Automatic codebar spring	40
Brush holder position	12	Bearing alignment	32
Brush holder spring	14	Bell clapper gap	48
Clutch latchlever spring	14	Blocking lever springs	39
Clutch shoe lever gap	11	Carriage drive bail endplay	48
Keyboard follower lever spring	13	Carriage return lever —	
Shaft left bearing gap	9	latch clearance	47

SECTION 574-122-700TC

CONTENTS	PAGE
Carriage return spring	48
Codebar guide position	106
Codebar reset bail spring	36
Codebar reset guide position	38
Codebar reset lever line-up	35
Codebar reset lever position	36
Codebar springs	40
End-of-line bell signal - S	105
End-of-line latch spring	101
Function bail spring	49
Function lever retainer	49
Function lever springs	42
Function pawl spring	41
Function shaft and casting position	46
Left rocker drive	41
Line feed function strip lever spring - S	42
Line length selection	101
Main shaft rotation	32
Margin bell bellcrank clearance	105
Print suppression and no. 4 codebar spring	40
Print suppression cam follower spring	45
Print suppression latch — horizontal clearance	37
Print suppression latch — vertical clearance	45
Right rocker drive	43
Rocker shaft position and endplay	31
Selector blocking levers positioning	39
Stripper bail clearance	44
 Main Shaft Area	
Clutch shoe lever spring	23
Clutch shoe spring	23
Codebar and function clutch shoe lever gaps	22
Codebar clutch endplay	17
Codebar clutch trip lever engagement	20
Codebar clutch trip lever line-up	19
Driven gear line-up	17
Form feed clutch endplay - S	18
Function clutch endplay	16
Function clutch position	16
Function clutch trip lever engagement	21
Latchlever endplay - S	18
Latchlever springs	22
Left bearing position	15
Selector cam endplay	15
Trip lever springs	21
Trip shaft latchlever endplay	19

CONTENTS	PAGE
 Motor Area	
Belt tension	34
Gear backlash	33
 Platen Area	
Cam zero position - S	96,97
Copyholder wire position - F	120
Detent position - F	111
Detent position - S	90
Detent ratchet pawl spring - S	90
Form length selection - S	107
Idler position - S	89
Left margin position - F	100
Left margin position - S	99
Line feed blocking lever spring - F	112
Line feed drive arm clearance - F	113
Line feed drive link position - F	115
Line feed drive link spring — horizontal - F	112
Line feed drive link spring — vertical - F	112
Line feed pawl downstop position - F	116
Line feed pawl spring - F	111
Line feed selection - F	110
Line feed stripper plate clearance - F	117
Line feed upstop bracket position - F	114
Paper guide springs - F	119
Paper guide spring - S	85
Paper guideplate clearance - S	94
Paper guideplate springs - F	119
Paper guideplate spring - S	85
Paper straightener bail spring - F	119
Platen detent pawl spring - F	115
Platen endplay - F	121
Platen — horizontal position - F	108
Platen — horizontal position - S	86,87
Platen knob position - S	85
Platen knob spring - S	85
Pressure roller clearance - F	118
Printing line position — final - S	92
Printing line position — preliminary - S	91
Reset follower lever — reset position - S	96
Right margin position - S	99
Right paper guide position - S	93
Vertical type alignment - F	109
Vertical type alignment - S	87,88
Wire guide position - S	95
Zeroizing button - S	89
 Selector Area	
Armature bracket position	25
Armature spring	26
Latchlever spring	27

CONTENTS	PAGE
Pushlever springs	29
Receiving margins	128
Selector clutch torque	30
Selector lever springs	28
Shoe lever gap and trip lever	
engagement	24
Spacing locklever spring	28
Start lever spring	27
Stripper bail spring	29
Trip lever spring	24
Spacing Area	
Carriage bounce	102
Carriage return arm springs	103
Carriage return latch spring	103
Carriage return lever spring	125
Carriage return lever — unlatch	
clearance	103
Check pawl spring	126
Feed pawl spring	123
Feed pawl stop position	122
Feed pawl travel	126
Left margin printing	104
Space bellcrank spring	122
Space suppression lever clearance —	
printing	124
Space suppression lever clearance —	
spacing	125
Space suppression lever spring	123
Spacing belt tension	98
3. VARIATIONS TO BASIC	
ADJUSTMENTS	130
Answer-Back Area	
Armature spring	133
Blocking follower lever spring	132
Blocking latch spring	133
Blocking link clearance	130
Character suppression contact	
wire gap	143
Contact wire spring	135
Control lever spring — horizontal	132
Control lever spring — vertical	
(early design)	133
Control lever spring — vertical	
(late design)	134
Detent spring	135
Drum position	136
Feed lever position	138
Feed lever spring	144
Feed pawl position	139
Feed pawl spring	135
HERE IS bellcrank	140
Tripbail positioning	141
Trip lever adjusting tab clearance	142
Trip lever clearance	137

CONTENTS	PAGE
Trip lever overtravel and	
armature gap	131
Trip lever spring	134
Trip magnet position	131
Auxiliary Contact Assembly —	
TP183594	
Front contact spring	152
Time delay contact bracket	
position	152
Function Box Switches	
Contact assembly position	145
Paper controls	
Paper alarm contact lever	
clearance - S	158
Paper alarm contact pressure	
and gap - S	158
Paper lever spring - S	158
Print-Nonprint	
Armature spring	155
Latch bellcrank spring	157
Nonprint codebar spring	154
Nonprint function lever clearance	153
Release magnet overtravel	157
Solenoid bracket position	155, 156
Receive-Only Sets	
Keyboard adjusting bracket	
position	146
Two-Color Printing	
Blocking link clearance	147
Color selection latch overtravel	150
Latch bellcrank spring	148
Ribbon guide positioning	151
Ribbon guide spring	148
Typewheel return spring	149

1. GENERAL

1.01 This section provides adjustment information for the 33 typing unit. New within this issue is (a) exclusive coverage of 33 typing unit, (b) engineering changes, (c) two-color printing and typing unit suppression features, (d) revised order of adjustments, (e) title changes (which now provide a functional description of the associated area). Marginal arrows indicating changes are omitted.

1.02 In the adjustments covered in this section, location of clearances, position of parts, and point and angle of scale applications

TELETYPE CORPORATION
Skokie, Illinois, U. S. A.

SECTION 574-124-700TC
Issue 2, July, 1967

33 TAPE READER

ADJUSTMENTS

CONTENTS	PAGE
1. GENERAL.	1
2. BASIC UNIT	5
Clutch Trip Area	
Armature extension	7
Contact gap	8
Feed magnet contact spring	9
Magnet core	5
Reader trip lever spring	9
Shoe lever	7
Trip magnet	5
Trip lever overtravel	6
Trip magnet armature spring	6
Tape Reader Area	
Armature spring	20
Blocking pawl	14
Blocking pawl spring	11
Contact wires spring	16
Control (or tape-out) contact wires	16
Control detent spring	19
Detent lever	10
Detent lever spring	10
Feed pawl (adjustment with gauge TP183103)	11
Feed pawl (adjustment without gauge TP183103)	13
Latch spring	21
Reader mounting bracket (early design)	22
Reader mounting bracket (late design)	23
Sensing contact wire spring	19
Sensing pin	15
Sensing pin spring	15
Start contact wires	17
Tape lid latch handle	18
Tape lid spring	18
Tape-out pin spring	20
Tight tape lever spring	19
Upstop spring	11
3. VARIATIONS TO THE BASIC UNIT	24
Reset and busy switch timing	24

1. GENERAL

1.01 This section provides adjustment and maintenance information for the 33 tape reader. It is reissued to provide exclusive coverage of the 33 tape reader and to update the section. Since this is a general revision, marginal arrows ordinarily used to indicate changes and additions are omitted.

1.02 In the adjustments covered in this section, location of clearances, position of parts, and point and angle of scale applications are illustrated by line drawings. Tools required to perform adjustments are contained in TP185830 Tool Kit and are listed in Maintenance Tool Section 570-005-800.

Note: An adjustment must be performed even if the accompanying illustration is not an exact duplication of the adjustment area.

1.03 The sequence in which the adjustments appear should be followed when a complete readjustment of the tape reader is undertaken. No adjustment should be undertaken without completely understanding the procedure and the requirements. Read a procedure all the way through before making an adjustment or checking a spring tension.

Note 1: Be sure to check all related adjustments (Paragraph 1.07).

Note 2: Remove all electric power before checking or performing adjustments.

1.04 References to left, right, front, rear, etc consider the tape reader to be viewed from a position where the feed wheel faces up and the lid latch is located to the viewer's right. Orientation references to the clutch trip area consider the armature extension to be facing up with the contact bracket pry points located to the viewer's right.

TELETYPE CORPORATION
Skokie, Illinois, U. S. A.

SECTION 574-125-700TC
Issue 3, July, 1967

33 TAPE PUNCH

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL.	1	Lever overtravel	21
2. BASIC UNIT	5	LOCK ON	26
Backspace lever spring	17	ON mechanism return spring	28
Chad chute extension	13	Sensing lever and bail gap	23
Codebar extension springs	14	Visual ON OFF indicator	25
Control detent lever spring	18	Miscellaneous	
Control pushbuttons	18	Folded tape guide	29
Detent lever spring	16	1. GENERAL	
Drive link spring	19	1.01 This section provides adjustment and	
Feed pawl spring	16	maintenance information for the 33 tape	
Feed wheel ratchet and pawl — final .	11	punch. It is reissued to provide exclusive cov-	
Feed wheel ratchet and pawl —		erage of the 33 tape punch and to update the	
preliminary	6	section. Since this is a general revision, mar-	
Pawl and lever springs	15	ginal arrows ordinarily used to indicate changes	
Pawl upstop assembly — final	10	and additions are omitted.	
Pawl upstop assembly —		1.02 Figure 1 shows the tape punch area where	
preliminary	5	the punch adjustments and spring tension	
Punch block assembly	19	checks are made.	
Punch penetration	9	1.03 In the adjustments covered in this sec-	
Sensing lever springs	14	tion, location of clearances, position of	
Stripper bail spring	15	parts, and point and angle of scale applications	
Stripper bail upstop	7	are illustrated by line drawings. Requirements	
Tape bias spring	13	and procedures are set forth in the several texts	
Tape guide compression spring	18	that accompany the line drawings. Required	
Tape guide tension spring	17	tools are included in TP185830 Maintenance Tool	
Tape nudger	5	Kit and are listed in Section 570-005-800.	
Tape punch drive	8	1.04 The sequence in which the adjustments	
Ten characters per inch	12	appear should be followed when a com-	
3. VARIATIONS TO THE BASIC UNIT . .	20	plete readjustment of the tape punch is under-	
Automatic Control Mechanisms		taken. No adjustment should be undertaken	
Automatic ON	27	without completely understanding the procedure	
Automatic punch interlock spring . . .	28	and the requirements. Read a procedure all the	
Control bail assembly	20	way through before making an adjustment or	
Control bail assembly spring	26	checking a spring tension.	
Feed wheel ratchet and pawl gap	22		
Latch bail gap	24		
Latch bail spring	22		

TELETYPE CORPORATION
Skokie, Illinois, U. S. A.

SECTION 574-126-700TC
Issue 1, January, 1968

33 COVERS

ADJUSTMENTS

CONTENTS	PAGE	Receive (KSR) and Automatic Send-Receive (ASR) Sets (Figures 1 and 2).
1. GENERAL	1	
2. BASIC UNIT	3	1.02 After completing an adjustment, replace cover and/or any parts that were removed. Check any adjustments affected by the removal of the cover and/or parts.
Call Control Area		
Dial to cover	3	CAUTION: ELECTRICAL POWER MUST BE REMOVED FROM UNIT BEFORE ANY ADJUSTMENTS ARE MADE.
Knob to bezel	3	
Paper Area		
Low paper contact operating arm . . .	4	1.03 In the adjustments covered in this section, location of clearances and position of parts are illustrated by line drawings. Requirements and procedures are set forth in the texts that accompany the line drawings.
Tape Punch Area		
Control pushbuttons	7	
Visual "ON-OFF" indicator	7	1.04 Reference to left, right, front, or rear, etc, consider the cover to be viewed from a position where the lid is up and the nameplate position is facing the viewer.
Tape Reader Area		
Reader mounting bracket (early design)	5	1.05 Unless specifically stated otherwise, position screws or nuts friction tight to make an adjustment, and tighten them securely once the adjustment has been made.
Reader mounting bracket (late design)	6	
1. GENERAL		1.06 Tools needed to perform adjustments are included in TP185830 maintenance tool kit and are listed in Section 570-005-800.
1.01 This section is issued to provide adjustment information for the 33 typing unit, tape punch, and reader covers. The requirements apply to covers for both Keyboard Send-		1.07 Check appropriate disassembly and re-assembly section for approved procedure of cover and parts removal.