



3. Set the switches on the rear panel of your plotter as shown in the following illustration. Your plotter checks the switch settings only when you turn it on, so be sure the plotter is turned off before changing the switch settings.



4. Connect the plotter to the computer. The following illustration shows an HP Vectra PC. Be sure you are using the correct cable for your computer and plotter.



Plotter Interconnection